



KEY #	DESCRIPTION	RSP30
1	DRAG KNOB ASSEMBLY	HP6.286.066.00
2	DRAG RETAINER	HP8.247.017.00
3	KEY WASHER	HP8.940.022.00
4	DRAG WASHER	HP8.940.279.00
5	EAR WASHER	HP8.940.142.00
6	SPOOL ASSEMBLY	HP6.323.340.00
(At the other parts)		
7	SPOOL WASHER	HP8.940.161.00
8	CLICK GEAR	HP8.498.002.06
9	ROTOR NUT	HP8.379.021.46
10	SCREW	HP8.903.039.00
11	MAIN SHAFT	HP8.300.121.06
12	ROTOR	HP8.077.129.00
13	ROTOR	HP8.625.252.00
14	BALANCE WEIGHT	HP8.345.074.00
15	KICK LEVER	HP8.605.163.04
16	BAIL SEAT	HP8.605.163.04
17	SCREW	HP8.903.017.00
18	BAIL ASSEMBLY	HP8.386.137.00
19	LINE ROLLER BUSHING	HP8.220.072.00
20	LINE ROLLER	HP8.322.015.03
21	LINE ROLLER WASHER	HP8.940.475.00
22	SCREW	HP8.072.029.00
23	ARM LEVER	HP8.072.029.00
24	LINE SLIDER SCREW	HP8.902.029.00
25	BAIL KICK LEVER	HP8.344.100.00
26	SPRING	HP8.382.094.00
27	SPRING	HP8.501.024.00
28	BAIL KICK LEVER SEAT	HP8.605.162.04
29	ARM LEVER COVER	HP8.605.162.04
30	ROTOR GUARD	HP8.531.206.04
31	SCREW	HP8.903.055.00

KEY #	DESCRIPTION	RSP30
30	CLUTCH ASSEMBLY	HP6.220.033.00
31	CLUTCH WASHER	HP8.940.303.00
32	CLUTCH SLEEVE	HP8.024.034.06
33	BALL BEARING	HP6.263.026.00
34	PINION GEAR	HP8.435.154.00
35	ANTI-REVERSE PAWL SCREW	HP8.903.041.00
36	ANTI-REVERSE PAWL	HP8.347.077.65
37	SPRING	HP8.383.061.00
38	ANTI-REVERSE CAM	HP8.344.089.65
39	ANTI-REVERSE LEVER	HP8.336.023.71
40	HANDLE SCREW CAP	HP6.425.025.04
41	HANDLE SCREW WASHER	HP8.940.123.00
42	BODY	HP8.074.121.00
43	BALL BEARING	HP6.263.021.00
44	DRIVE GEAR	HP8.435.095.65
45	ADJUST WASHER	HP8.940.345.00
46	BALL BEARING	HP6.263.023.00
47	BODY COVER	HP8.080.116.00
48	SCREW	HP8.903.025.00
49	O/S GEAR BUSHING	HP8.415.136.00
50	O/S GEAR	HP8.210.134.06
51	O/S SLIDER	HP8.204.046.65
52	MAIN SHAFT SCREW	HP8.902.094.00
53	BODY BUTT CAP	HP8.531.184.04
54	SCREW	HP8.903.064.00
55	HANDLE ASSEMBLY	HP6.353.124.00
56	BALANCE WEIGHT	HP8.625.250.00
57	SCREW	HP8.903.065.00
58	ANTI-REVERSE PAWL SPRING	HP8.383.062.00