



RSP220 RSP230

Gen220 Gen230

| NUMER | PARTS NAME                       | NUMER | PARTS NAME            |
|-------|----------------------------------|-------|-----------------------|
| 1     | DRAG KNOB ASSEMBLY               | 23    | BALL BEARING          |
| 2     | SPOOL ASSEMBLY                   | 24    | BALL BEARING RETAINER |
| 3     | CLICK WASHER                     | 25    | ONE WAY CLUTCH        |
| 4     | CLICK GEAR                       | 26    | PINION GEAR           |
| 5     | ROTOR SCREW                      | 27    | STOPPER CAM           |
| 6     | ROTOR NUT                        | 28    | STOPPER SPRING        |
| 7     | ROTOR                            | 29    | STOPPER LEVER         |
| 8     | KICK LEVER                       | 30    | STOPPER LEVER SCREW   |
| 9     | SPRING SHAFT                     | 31    | HANDLE ASSEMBLY       |
| 10    | ARM LEVER COVER                  | 32    | BODY                  |
| 11    | ARM LEVER COVER SCREW            | 33    | REAR COVER            |
| 12    | BAIL ARM SPRING                  | 34    | REAR COVER SCREW      |
| 13    | COUNTER WEIGHT                   | 35    | O/S GEAR BUSHING      |
| 14    | MAIN SHAFT                       | 36    | O/S GEAR              |
| 15    | GUIDE SCREW                      | 37    | SLIDER                |
| 16    | ARM LEVER                        | 38    | MAIN SHAFT SCREW      |
| 17    | ARM LEVER BUSHING                | 39    | BODY BALL BEARING     |
| 18    | LINE ROLLER                      | 40    | DRIVE GEAR            |
| 19    | BAIL ASSEMBLY                    | 41    | BODY COVER BEARING    |
| 20    | ARM LEVER AND HOLDER COVER SCREW | 42    | BODY COVER            |
| 21    | CLUTCH STACK RETAINER SCREW      | 43    | BODY COVER SCREW      |
| 22    | CLUTCH STACK RETAINER            | 44    | HANDLE ASSEMBLY       |