


# RSPB6



Key Number	Description	RSPB6
1	Drag Knob Assembly	HRR332-02
2	Drag Retainer	HRR036-02
3	Drag Washer "D" Keyed to Reel	HRR080-02
4	Drag Washer "B"	HRR039-02
5	Drag Washer, Keyed to Spool	HRR081-04
6	Drag Washer "B"	HRR039-02
7	Drag Washer "D" Keyed to Reel	HRR080-02
8	Drag Washer "B"	HRR039-02
	Spool Assy.	HRR321-02
J	Screw	HRS094-02
11	Rotor Nut Fixed Plate	HRS214-01
12	Rotor Nut	HRS006-02
13	Rotor Washer	HRR065-02
14	Bail Arm "A"	HRR007-02
15	Bail Axel Retainer Screw	HRS108-01
16	Bail Retainer Screw	HRR051-01
17	Line Roller Bushing	HRR016-01
18	Bail Axel Washer	HRS102-01
19	Line Roller	HRR004-02
20	Bail Seat	N/A
21	Bail Assy.	HRR347-02
22	Bail Latch Cover	HRR087-02
23	Arm Lever Retainer Plate	HRR141-01
24	Arm Lever Spring Shaft	HRR031-02
25	Arm Lever Spring	HRR049-02
26	Arm Lever Spring Holder	HRR020-02
27	Rotor	HRR009-02
28	Bail Trip Lever	HRR019-02
29	Screw	HRS094-02
30	Kick Lever Cover	HRR046-02
31	Click Gear Washer	HRS030-02
32	Click Gear (Spool)	HRR037-02
32	Drag Click Gear	HRR075-02
33	Center Shaft	HRR015-02
34	Clutch Assmably	HRR360-02
35	Bearing Retainer	HRR040-02
36	Bearing Screw	HRR041-02
37	Pinion Bearing	HRR028-02
38	Pinion Bearing	HRR028-02
	Pinion	HRR011-02
	Anti-Reverse Knob	HRR059-02
41	Screw	HRS077-01
42	Anti-Reverse Pawl	HRR063-02

Key Number	Description	RSPB6
43	Anti-Reverse Pawl Springs	HRR061-01
44	Anti-Reverse Pawl Retainer	HRR099-01
45	Crank Shaft Bushing	HRR027-02
46	Crank Gear	HRR012-02
47	Handle Screw Cap Washer	HRS105-02
48	Crank Shaft Bushing	HRR027-02
49	Handle Screw Washer	HRR105-02
50	Handle Retainer Screw Cover	HRR073-01
51	Body Cover	HRR023-02
52	Side Plate Screw	HRS057-02
53	Side Click Plate	HRR094-01
54	Side Click Plate Spacer	HRR132-01
55	Oscillator Gear	HRR053-02
56	Oscillator Slider	HRR025-02
57	Oscillator Slider Retainer	HRR078-02
58	Rear Clutch Retainer Screw	HRR034-02
59	Rear Clutch Assy.	HRR365-02
60	Anti-Reverse Clutch Spring	HRR044-01
61	Screw	HRS094-02
62	Main Body Assembly	HRR301-02
63	Anti-Reverse Lever	HRR059-01
64	Stop lever Screw	HRR135-01
65	Anti-Reverse Actuator Spring	HRR089-02
66	Rear Anti-Reverse Pawl	HRR074-01
67	Anti-Reverse Actuator	HRR090-02
68	Rear Clutch Retainer Screw	HRR108-01
69	Rear Clutch Retainer	HRR140-01
70	Thumb Bar Left Side	HRR137-02
71	Thumb Bar	HRR138-02
72	Thumb bar Right Side	HRR139-02
73	Thumbbar Retainer Screw	HRR054-01
74	Thumb Bar Lever Screw	HRR054-04
75	Rear Drag Washer	HRR039-04
76	Drag Click Gear	HRR075-02
77	Spur Gear	HRR055-01
78	Rear Drag Washer	HRR039-03
79	Drag Washer, Keyed to Spool	HRR081-03
80	Drag Retainer	HRR083-01
81	Drag Spring	HRR042-01
82	Drag Knob Assy.	HRR032-02
83	Handle Assembly	HRS318-02
84	Bail Flip Lever Spacer	HRR144-02